

DTS-P300 New Air Compressor Introduction



Model	DTS-P300
Voltage frequency	100V/60HZ 220/50HZ
Power	0.6KW
Nominal volume flow L/min@0.4Mpa	60
Noise	45dB
RPM	1380
Gas Cylinder	1L
Product Size	440*270*300mm
Package Size	515*335*375mm
N.W.	16KG
G.W.	19.5KG

Descriptions:

1.The overall lines are more graceful, and the accessories and functions are more reasonably arranged, making it easier for users to operate and use.

2.The size and weight of the whole machine have been fully optimized, it's light, small and more beautiful.

3.An air pressure gauge is installed on the fuselage, which can display the air pressure in real time when used as a set or independently.

4.A pre-condenser and a water vapor filter are installed at the air outlet of the product. When used together, the water removal effect is significant. Improvement, verified by testing, can ensure that no water vapor is generated at the air outlet during daily use.

5.Power supply safety upgrade, the original three-in-one switch is upgraded to a dual fuse configuration to improve the product safety index.

6. There is sound-absorbing cotton inside the box, which can significantly reduce working noise and improve user experience.